


エコフロアパネル



パネル

499 × 499 × 42.5 mm




ポリプロピレン

2つのケーブル穴付き(カバー有)
パネルF106とF107を使用し連結可能
2.57 kg




500 角

F308



EP1



EP2



ハーフ

F310



F310 - 左




F310 - 右




スロープ

F315



F315 - 左



F315 - 右



奥行
2700 用

R150



R150 - 左



R150 - 右



奥行
5400 用

R111




R111 - 左



R111 - 右



エッジLED アングル



S0630
ストレート

L2996


スロープ使用時調整部材
S0630・250
L250

端用 45度カット
S0630・左

S0630・右

L1490

L1490



エコフロアのエッジに取り付け、LEDテープを
仕込むことが可能。

※LED 部材はレンタルではありません。
別途、電気工事を手配してください。

奥行 2700 用

L1206

奥行 5400 用


L910

奥行 8100 用

L614


かさ上げ・連結部材・カバープレート

かさ上げ部材




F312

F308 の下部に組みこむ事で H100 の床となる




カバープレート
89 × 89 × 19 MM



F 106.33

ポリプロピレン
2つのパネルF300またはF302を連結するプレート
0.04 kg




カバープレート
89 × 44.3 × 19 MM



F 107.33

ポリプロピレン
2つのパネルF300またはF302の角に取り付けるプレート
0.02 kg



専用工具

工具(小)



F 1.90

プラスチック/スチール
パネルF300のカバーを取り外す工具



工具(大)




F 2.00

ステンレススチール
パネルF300のカバーを取り外す工具
1.02 kg

①



F308
500x500
x 100枚




EP1
500x474
x 40枚




EP2
474x474
x 4枚


②



③



④



F308
500x500
x 256枚



EP1
500x474
x 64枚



EP2
474x474
x 4枚

⑤




F308
500x500 x 280枚




EP1
500x474 x 76枚




EP2
474x474 x 4枚




⑥



⑦



⑧



⑨

